



11 TOOL FOR ALIGNING & SPACING ④ & ⑤ WHEN LOCATING CORE IN ⑥ - CLAMP TOGETHER

13 TOOL FOR FINAL XEROING OF CORES ON ⑥ IN TORQUE LVDT'S.

12 TOOL FOR FIXING AZIMUTH OF ④ OVER ⑤ WHEN LOCATING CORE IN ⑥

DIMENSIONS IN MILLIMETRES DO NOT SCALE

TOLERANCES ± UNLESS STATED



PATERSON INSTRUMENTS PTY LTD  
HPT TESTING MACHINE  
INTERNAL LOAD CELL - LVDT VERSION  
WIRING DIAGRAM & TOOLS